



INSTALLATION INSTRUCTIONS

CARBURETOR TEST GAUGE KIT 7861

For Holley 0-6895 or HP 0-80507 390CFM Carburetor

This kit is designed to check the Holley 0-6895 or HP 0-80507 390CFM carburetor. All of the test gauges are of the "NO-GO" design which means if the gauge fits into or over the item being checked, the carburetor is illegal. The kit consists of the following gauges:



78611 Venturi Gauge - This gauge will fit around the booster from the top and should not go into the venturi. This would also be a good time to check the venturi bore to see if it has elongated of "Egg-Shaped". This condition will be easy to spot at this time, as the gauge will not go in but you can see light around the front and backside of the gauge showing the venturi has been altered. Do not question a slight imperfection, as a cheated up venturi will be easy to spot.



78612 Throttle Bore Gauge - This tool should not go into any of the throttle bores.



78614 Combined Throttle Shaft and Plate Gauge - This gauge should not go over the throttle shaft and plate combined.



78594 Booster Length Gauge - This gauge will go into the venturi and check the height or length of the booster. If it fits over the booster has been altered.



78595 Booster I.D. and O.D. Gauge - This gauge can be used from the top. One end is slotted to check the booster O.D. The top of the booster has a normal taper by design where the gauge will initially go over the top, but should not go below the casting line in the middle. The other end contains a .118" pin gauge that checks the booster cross bar width. The pin should not go between the booster cross bar and the I.D. of the booster.



78596 Booster Bottom O.D. Checking Gauge - Turn the carburetor upside down and open the throttles. You will now have room to insert the gauge at an angle to check the booster outside diameter at the bottom of the booster. If the gauge goes over the booster at any point the booster has been altered. This is the most common alteration of the 600 carburetor and power gains of up to 10HP are common by tapering the booster below the .615 allowed. **NOTE:** The booster has a normal taper by design but should not be less than the gauge of .615. This is a very important area to check.



78607 Booster Locating Tool - This tool is used to check and see if the booster has been relocated and raised in the main body. The gauge is designed to set on top of an HP main body side to side directly over the booster.

BLP Racing Products, LLC

1015 West Church Street
Orlando, Florida 32805
407.422.0394
800.624.1358
407.422.2741 FAX

WWW.BLP.COM

HOLLEY CARBURETOR SPECIFICATIONS:

Venturi Bore Pri and Sec	1.060 - 1.064	Booster leg pin gauge	.117
Booster O.D. at parting line	.626 - .630	Booster Length	.720 (+ or -) .010
Booster O.D. at top and bottom	.614 - .618	Throttle Bore Pri and Sec	1.4365 - 1.4385
Booster I.D.	.442 - .446	Combined Throttle Shaft & Plate	.1995 - .2085
Booster cross leg width	.220 - .226		

Originally Founded In 1965 by
BO LAWS

08-2013